

# EHP

### Electronic High Pressure Controller INSTALLATION & OPERATING INSTRUCTIONS

The EHP is a complete closed loop controller consisting of two internal solenoid valves, a manifold, an electronic control circuit and a pressure transducer all contained in a protective IP65 rated housing. It controls the downstream pressure under static conditions in a range of calibrated pressures up to 500 psig (35 bar(g)).



### Contents

2	Specifications	Serial Configurations	8-10
2	Operational Description	Serial Commands	10
3	Dimensions	Serial Connection	11
3	Mounting	Ordering Information	12
4	Pneumatic Plumbing	Accessories	12
4	Calibration / Recalibration	Warranty Information	12
5-6	Analog Electrical Connections	Safety Information	13
7	Serial PuTTY Configuration	Contact Information	13

# Equilibar's quality system is **ISO 9001:2015** certified.

Equilibar, LLC Tel: +1-828-650-6590 inquiry@equilibar.com



Please read all of the following Safety Precautions before installing or operating any Equilibar, LLC. equipment or accessories. To confirm safety, be sure to observe 'ISO 4414: Pneumatic Fluid Power - General rules relating to systems' and other safety practices. Improper operation could result in serious injury to persons or loss of life!

#### 1. OVERPRESSURIZATION

The EHP electronic pressure regulator is not a safety device and must not be relied upon to prevent dangerously high pressures. Where danger from overpressurization exists then an additional valve that is designed and marketed as a safety pressure relief valve must be used to protect the EHP against excess supply pressure and to protect the system should the EHP produce excess pressure on its outlet.

#### 2. PRODUCT COMPATIBILITY

Equilibar EHP and accessories are for use in industrial pneumatic applications with compressed air or inert gas media. The compatibility of the equipment is the responsibility of the end user. Product performance and safety are the responsibility of the person who determined the compatibility of the system. Also, this person is responsible for continuously reviewing the suitability of the products specified for the system, referencing the latest catalog, installation manual, Safety Precautions and all materials related to the product.

#### **3. EMERGENCY SHUTOFF**

Equilibar products cannot be used as an emergency shutoff. A redundant safety system should be installed in the system to prevent serious injury or loss of life.

#### 4. EXPLOSIVE ATMOSPHERES

The EHP Series should not be used where harmful, corrosive or explosive materials or gases are present. Unless specifically certified and labeled, Equilibar, Inc. products cannot be used with flammable gases or in hazardous environments.

#### 5. COMPRESSED GAS QUALITY

Filtered, clean, dry, non corrosive compressed gas is required for this product. Additionally, a 40 micron particulate filter is installed by the factory to prevent solid contamination from entering the product. Do not remove this filter. This filter is intended as a last ditch defense and does not negate the need for the user to supply filtered, clean, dry, non corrosive compressed gas. Only neutral gases should be used.

#### 6. TEMPERATURE

Products should be used with a media and ambient environment inside of the specified temperature range of 32°F to 158°F. Consult factory for expanded temperature ranges.

#### 7. OPERATION

Only trained and certified personnel should operate electronic and pneumatic machinery and equipment. Electronics and pneumatics are very dangerous when handled incorrectly. All industry standard safety guidelines should be observed.

#### 8. SERVICE AND MAINTENANCE

Service and maintenance of machinery and equipment should only be handled by trained and experienced operators. Inspection should only be performed after safety has been confirmed. Ensure all supply pressure has been exhausted and residual energy (compressed gas, springs, gravity, etc.) has been released in the entire system prior to removing equipment for service or maintenance. Be sure to employ lock out / tag out procedures.



WARNING Improper operation could result in serious injury to persons or damages to equipment

#### **1. PNEUMATIC CONNECTION**

All pipes, pneumatic hose and tubing should be free of all contamination, debris and chips prior to installation. Flush pipes with compressed air to remove any loose particles. EPC ships with sintered filter installed in the inlet with at least 40-micron filtration. The EPC is extremely sensitive to dirt and debris.

#### 2. THREAD SEALANT

To prevent product contamination, thread tape is not recommended. Instead, a non- migrating thread sealant is recommended for installation. Preferred sealant for 1/8" NPT port is Loctite 545 or face seal. Apply sealant two threads from the end of the pipe thread to prevent contamination.

#### 3. ELECTRICAL CONNECTION

To prevent electronic damage, all electrical specifications should be reviewed and all electrical connections should be verified prior to operation.

### INSTALLATION AND MAINTENANCE INSTRUCTIONS

### **OPERATIONAL DESCRIPTION**

The EHP is an electronic high pressure regulator that controls the pressure at its outlet port based on an electrical command signal input. The EHP is available in a range of calibrated pressures up to 500 psig (35 bar(g)). It can be configured for 0 -10 VDC or 4-20 mA analog signal types or 3.3V serial digital.

The EHP is a complete closed loop controller consisting of two internal solenoid valves, a manifold, an electronic control circuit and a pressure transducer all contained in a protective IP65 rated housing. One solenoid valve functions as inlet control allowing supply media into the system which increases the controlled pressure. The other solenoid valve acts as the exhaust and will decrease the controlled pressure by venting to atmosphere.

The controlled output pressure is measured by the onboard pneumatic pressure sensor and compared to the desired (target) pressure by the EHP's internal electronics. When the circuit detects a difference between the targeted command pressure and the actual output pressure, the circuit will energize the appropriate solenoid valve to raise or lower the pressure back to the targeted value.

The EHP is a relatively low flow regulator. This makes it a great choice any time low flow rates or small volumes require precise pressure control. The EHP can be used to provide the pilot pressure signal to the dome of an Equilibar<sup>®</sup> back pressure regulator allowing electronic control of back pressure in line sizes from 1/8 inch through 4 inch by pilot operating the appropriately sized regulator.



### **SPECIFICATIONS**

ELECTRICAL	
SUPPLY VOLTAGE	15-24 VDC
SUPPLY CURRENT	<250 mA max.
	0-10 VDC
COMMAND SIGNAL OPTIONS	4-20 mA (differential)
	3.3 V Serial Digital
PERFORMANCE	
ACCURACY	±0.5% of Full Scale
RESOLUTION	<u>≤</u> 50 mV
LINEARITY	<u>&lt;</u> 0.2%
MAX HYSTERESIS	<u>&lt;</u> 0.25%
RESPONSE TIME	< 20 ms typical (application dependent)
OPERATING CONDITIONS	
PRESSURE RANGE	0 - 500 psig
MEDIUM	Clean, dry, non-corrosive gases
OPERATING TEMPERATURE	32 to 180 °F (0 to 82°C)
RECOMMENDED FILTRATION	40 micron nominal
MOUNTING ORIENTATION	ANY
PHYSICAL	
PORT SIZE	1/8" NPT
	Elastomers - Flourocarbon
WETTED PARTS	Manifold - Anodized aluminum
	Valves - Nickel plated brass
	Pressure sensor - 17-4 PH Stainless Steel
HOUSING	Polycarbonate
PROTECTION RATING	IP65

Equipment used for test and calibration is NIST traceable

### **EHP DIMENSIONS**



MOUNTING

The EHP is not sensitive to position and may be mounted in any orientation. It comes standard with convenient (bottom or side) mounting holes for easy mounting to most flat surfaces. An optional sheet metal bracket is available that allows the EHP to be rear mounted or foot mounted. See page 12 for bracket ordering information.



Mounting Bracket (optional)



### PNEUMATIC PLUMBING CONNECTIONS

The inlet (IN) port connects to the supply pressure with a 1/8" NPT fitting. A 40 micron sintered filter is pre-instealled in the inlet port. Do not remove this filter. The recommended supply pressure depends on the calibrated range and is listed in Table 2 below. Supply the EHP with only clean, dry, non-corrosive gas.

The outlet (OUT) port connects to the process to be controlled with a 1/8" NPT fitting. For best stability, the tubing between the outlet and the controlled process requires a minimum volume of 2 cubic inches. The EHP is commonly used as a pilot pressure controller for an Equilibar fluid control valve. In that case, the outlet piping would lead to the pilot port of the Equilibar back pressure regulator or flow control valve.



### CALIBRATION / RECALIBRATION

All EHP control valves come calibrated from the factory by trained personnel using precision calibration equipment. The calibration and operation of each EHP valve is checked by two different operators using independent test equipment. The EHP valve is a closed loop control valve using a precision electronic pressure sensor. Typical drift is less than 1% over the life of the product.

The EHP is calibrated to NIST standards when manufactured and the PID values are set to the EHP standard tuning. If specific application details are known prior to manufacture (recommended), the PID values may be tuned in accordance with the known specifications to provide the most stable and repeatable control.

If your EHP valve appears to be out of calibration by more than 1%, it is not likely to be the EHP. Check the system for adequate supply pressure, wiring and electronic signal levels. Verify the accuracy of your measuring equipment before re-calibrating. Consult factory if you have any questions or require assistance. If the calibration needs to be changed or modified, the unit must be returned to Equilibar. Any attempt to recalibrate in the field without prior authorization will void the warranty.

#### Table 2

#### Rated Inlet Pressure for Calibrated Range

CALIBRATED RANGE	MIN INLET PRESSURE <sup>1</sup>
0 to 200 psig	220 psig
0 to 300 psig	330 psig
0 to 400 psig	520 psig

<sup>1</sup> MAX INLET PRESSURE for all calibrated ranges is 550 psig

### ANALOG ELECTRICAL CONNECTION FOR 0-10 VDC INPUT COMMAND SIGNAL



Make sure AC power is disconnected before DC connections are made

The EHP requires 15 to 24 VDC on **Pin 8** of the electrical connector. It uses 0 to 10 VDC command signal on **Pin 1** of the electrical connector. The power supply ground, command source ground and **Pin 3** must be tied together. If the analog monitor signal is being used, utilize **Pin 5** to send the 0 to 10 VDC signal to a measuring device like a volt meter, panel meter or acquisition device.



Fig:4

### Table 3 EHP Electrical Pin-out for 0-10V Command

PIN NUMBER	FUNCTION	COLOR
1	+Command Input	White
2	3.3 V Serial TX	Brown
3	DC Common/Ground	Green
4	Not Used	Yellow
5	Analog VDC Output	Gray
6	Not Used	Pink
7	3.3 V Serial RX	Blue
8	Power, 15-24 VDC	Red

Red LED: Power to Unit ON Solid Blue LED: Analog Mode Flashing Blue LED: 3.3 VDC Serial Mode

*Reference Serial Configuration Section for Command Change Instructions* 



### ANALOG ELECTRICAL CONNECTION FOR 4-20 MA COMMAND SIGNAL

Make sure AC power is disconnected before DC connections are made

The EHP requires 15 to 24 VDC on **Pin 8** of the electrical connector. An EHP configured for Current Command uses a differential current loop scheme (not isolated), meaning current flow is from **Pin 6** to **Pin 4**. Some applications may require the common of the power supply that provides loop power for the 4-20mA command to be tied to power supply common **pin 3**. If the analog monitor signal is being used, utilize **Pin 5** to send the 4 to 20 mA signal to a measuring device like a ammeter, panel meter or acquisition device.



### Table 4 EHP Electrical Pin-out for 4-20mA Command

PIN NUMBER	FUNCTION	COLOR
1	Not Used	White
2	3.3 V Serial TX	Brown
3	DC Common/Ground	Green
4	-4 to 20 mA Command Return	Yellow
5	4 to 20 mA Output	Gray
6	+4 to 20 mA Command Input	Pink
7	3.3 V Serial RX	Blue
8	Power, 15-24 VDC	Red

Red LED: Power to Unit ON Solid Blue LED: Analog Mode Flashing Blue LED: 3.3 VDC Serial Mode

Reference Serial Configuration Section for Command Change Instructions



### SERIAL CONFIGURATION



Software is required in order to communicate via 3.3V serial with the EHP. Many serial software communication solutions are available; If you already have a software solution, please ensure it is configured with the specifications listed in Table 6 prior to making the electrical connections to EHP. The commands can be found in Table 7 on Page 10.

If you do not already have a serial software solution, we recommend PuTTY as a free and open-source solution. PuTTY is one of the most common software packages used for serial communication and can be downloaded here: https://putty.org/

Once downloaded and installed on your windows-based machine, please follow the steps on the following pages to configure the software prior to making the electrical connections to the EHP. The specifications to configure and/or confirm within PuTTY are listed in Table 6.

SETTING LABEL	SPECIFICATION
Speed (baud)	57600
Data Bits	8
Stop Bits	1
Parity	None
Flow Control	None
Serial Line	See Steps 1&2

#### Table 6 Serial Software Configuration (PuTTY)

#### **Recommended Proportional Adjustment Values**

ORIFICE SIZE	ADJUSTMENT
0.009″	25
0.013″	10
0.026"	5
0.052″	1

### **Recommended Integral Adjustment Values**

ORIFICE SIZE	ADJUSTMENT
0.009″	0.1
0.013″	0.05
0.026″	0.05
0.052"	0.05

SERIAL CONFIGURATION | CONTINUED

**STEP - 1** 

🛃 Device Manager File Action View Help 1. Ensure proper serial connection to EHP 🗢 🔿 🗊 😰 📰 💭 unit and then connect 3.3 V serial to the DESKTOP-FL8QVF3 Audio inputs and outputs Batteries Bluetooth control device. The wiring schematics can be found on page 11. Disk drives
 Display adapters
 Firmware 2. Open Device Manager and identify the Human Interface Devices IDE ATA/ATAPI controllers serial port assigned to the serial cable. Imaging devices Imaging Intel(R) Dynamic Platform and Thermal Framework Keyboards Mice and other pointing devices Monitors Ports (COM & LPT) USB Serial Port (COM3) Processors Security devices E Sensors Software components Software devices Sound, video and game controllers Storage controllers >>> Website: Many ways to open Device Manager System devices https://www.digitalcitizen.life/ways-open-device-manager-windows Universal Serial Bus controllers USB Connector Managers

### **STEP - 2**

🕵 PuTTY Configura	ation			?	$\times$
Category:					
Category: Session Logging - Terminal - Keyboard - Bell - Features - Window - Appearance - Behaviour - Translation - Colours - Connection - Data - Proxy - Telnet - Rlogin - SSH - Serial	Sp Sc C Lo Si C C	Basic option recify the destination y erial line OM3 onnection type: ) Raw O Telnet ad, save or delete a s aved Sessions Default Settings	er Only on cl	ssion Speed 57600 H Seria Load Save Delete	a)
About	Hala		0.5.55	Canad	
About	Help		Open	Cancel	

- 1. Open installed Putty program
- 2. Ensure 'Serial' is selected

SERIAL CONFIGURATION | CONTINUED

**STEP - 3** 

Input the port identified in Step-1 into the Serial line, as shown

#### Category: - Session Basic options for your PuTTY session Logging Specify the destination you want to connect to - Terminal Serial line Speed Keyboard Bell COM3 57600 Features Connection type: Window ◯Raw ◯Telnet ◯Rlogin ◯SSH ●Serial Appearance Behaviour Load, save or delete a stored session Translation Saved Sessions Selection Colours Connection Default Settings Load Data Proxy Save Telnet Rlogin SSH Delete Serial Close window on exit O Always O Never Only on clean exit About Help Open Cancel

### **STEP - 4**

Change the speed (baud) setting to: 57600

Session	Basic options for your Pu	uTTY session
Eogging	Specify the destination you want to c	onnect to
Keyboard	Serial line	Speed
Features		57600
Window Appearance	Raw Telnet Rlogin	◯ SSH
Behaviour	-Load, save or delete a stored session	on
Selection	Saved Sessions	
Colours		
Data	Default Settings	Load
Proxy Telnet		Save
Rlogin		Delete
SSH     Serial		
	Always Never O	nly on clean exit
About		Canaal
About	elp Oper	n Cancel

### **STEP - 5**

STEP - 6

### Change Data Bits to 8 and Stop Bits to 1

Category:	Ontions controllin	n local serial lines
Cogging     Terminal     Keyboard     Bell     Features     Window     Appearance     Behaviour     Translation     Selection     Colours     Connection     Data     Proxy     Telnet     Rlogin     SSH     Serial	Select a serial line Serial line to connect to Configure the serial line Speed (baud) Data bits Stop bits Parity Flow control	COM3 57600 8 1 None ~
About H	lelp	Open Cancel

# Ensure both Parity and Flow Control are set to None

<b></b>		
Category:		
Session	Options control	olling local serial lines
Logging	Select a serial line	
Keyboard	Serial line to connect to	COM3
- Bell Features	Configure the serial line	
-Window	Speed (baud)	57600
Behaviour	Data bits	8
Selection	Stop bits	1
Colours	Parity	None ~
- Data	Flow control	None ~
Telnet		
Serial		
About Help		Open Cancel

### SERIAL CONFIGURATION | CONTINUED

### **STEP - 7**

### **STEP - 8**

In Terminal settings, check the boxes for: Implicit CR in every LF & Implicit LF in every CR



Note: If you would like feedback as you type, set the Local Echo to "Force On"

### SERIAL COMMANDS

Table 7

Proceed to making the electrical connections for the EHP following the wiring schematics on the next page.

Once the EHP is connected and the software is configured, the commands in Table 7 below can be used to change settings, request feedback and control the device.

DESCRIPTION	COMMAND ABREVIATION	INSERT TO SEE CURRENT VALUES <sup>1</sup>	INSERTED EXAMPLE CHANGES <sup>2</sup>	READABLE	WRITABL
Model No.	ID	?ID	n/a	Y	Ν
Serial Number	SN	?SN	n/a	Y	N
Proportional "P" Value	PIDP	?PIDP	PIDP: 100	Y	Y
Integral "I" Value	PIDI	?PIDI	PIDI: 0.75	Y	Y
Command Type (0=Analog, 1=Digital)	СТ	?CT	CT: 1	Y	Y
Current Command (0 - 100% of Full Scale)	CC	?CC	CC: 50	Y	Y
Monitor Output Signal from Internal Sensor	MON	?MON	n/a	Y	Ν
Save Settings to ROM	SAVE	n/a	SAVE	Ν	Y

**EHP | Serial Commands** 

<sup>1</sup>When entering any reading command, always prefix with "?". Example- ?PIDP

<sup>2</sup>Be sure to leave one space between the colon and the value when making changes. Example- PIDP: 100

SERIAL CONNECTIONS



The EHP requires 15 to 24 VDC on **Pin 8** of the electrical connector. It uses serial communication on **Pin 7** to receive and **Pin 2** to send digital responses. The power supply ground, command source ground and **Pin 3** must be tied together.



#### Table 9 EHP Electrical Pin-out for Serial Connection

PIN NUMBER	FUNCTION	COLOR	
1	+Command Input	White	
2	3.3 V Serial Digital TX	Brown	
3	DC Common/Ground	Green	
4	Not Used	Yellow	
5	Analog VDC Output	Gray	
6	Not Used	Pink	
7	3.3 V Serial Digital RX	Blue	
8	Power, 15-24 VDC	Red	



### ORDERING INFORMATION

		1	2	3	4	5	6
EXAMPLE PART NUMBER		ЕНР	н	F	E	3G	н
Your Part Number:		EHP	Н				
1	MODEL						
EHP	Electronic High Pre	essure					
2	ТҮРЕ						
н	IP65 Housing						
3	PORT THREAD TY	'PE					
F	1/8" NPT						

**G** G1/8 (option available)

(Items listed in blue are often in stock for faster delivery)

4	INPUT SIGNAL COMMAND
E	0 to 10 VDC
Т	4 to 20 mA (differential)
R	3.3V Serial Digital
5	PRESSURE RANGE
2G	0 to 200 psig
3G	0 to 300 psig
5G	0 to 500 psig
6	MIN VOLUME / MAX FLOW RATE
G	≥0.75 in³ / 3.0 lpm

H ≥1.00 in<sup>3</sup> / 6.5 lpm

I ≥2.00 in<sup>3</sup> / 12.5 lpm

### Accessories | Cables





### **Accessories** | Mounting Bracket

EPCH-B2

**Foot Mount** 



Bracket: Same bracket can be used for foot mounting or rear mounting.



**\_**ЕХН

 $\oplus$ 

 $\oplus$ 0

0

 $\oplus$ 

 $\bigcirc$ 

0

0  $\oplus$ 

www.equilibar.com February 2025 R2

Accessories | Filter

Molded Actuation Cable, 8-Pin, 6'



**Replacement Filter** 

3.3 V Serial Cable, 3'

() О О О Т

### LIMITED WARRANTY

All information contained in this publication is for reference only. Proper design engineering procedures should be used to assure any compliances. Equilibar, LLC. reserves the right to make changes without notice and does not warrant or guarantee the information contained herein.

Equilibar, LLC (Seller) warrants its products to be free from defects in material and workmanship for a period of one (1) year from the date of sale. Seller's liability shall be limited at seller's option to repair, replace or refund purchase price of product found by seller's examination to be defective. All claims under this warranty must be made in writing to seller's factory sales department giving full details, prior to return of product, postpaid, to factory. Seller shall not be responsible for product failure due to normal wear, accident, buyer's misapplication, abuse, neglect or alteration of product. Seller will not be responsible for any consequential damages. Equilibar makes no other warranty of any kind, expressed or implied. Circuits shown in this manual are for instructional purposes only. All circuits used on equipment and machinery should be thoroughly tested by qualified personnel under actual working conditions to determine their suitability for buyer's intended use. All technical data and operations are average values based on standard production models. Some deviations can be expected, and considerations of use and environments and clean, dry, oil-free air supply. Dimensions stated may be nominal and are subject to change without notice. Contact Equilibar for specific dimensional tolerances when dimensions are critical.

Equilibar, LLC 320 Rutledge Rd. Fletcher, North Carolina 28732 United States Tel: +1-828-650-6590 inquiry@equilibar.com

Equilibar's quality system is **ISO 9001:2015** certified.